

THE POWER SUPPLIER™

Features:

- Universal AC input / Full range
- Programmable output Voltage (0% ~ 105%)
- Programmable output Current (0% ~ 105%)
- High power density 16.3W / inch³
- Forced current sharing at parallel operation
- Constant current limit
- Selectable +5V / 0.5A or +9V / 0.3A auxiliary output
- Global control via RS232
- Remote setting multiple PSU via RS232, RS485 & I²C
- Power OK signal
- Remote ON / OFF, Remote sense function

EMC directives.

7. This test is done without enclosure.

- Protection: OVP, OLP, OTP, SCP, Fan failure
- 3 years warranty






REV. A9 14/05/21

3 years w	rairailly				ZERTIFIZIERT	0 2000000000			
	MODEL	AEK-3000-12	AEK-3000-15	AEK-3000-24	AEK-3000-30	AEK-3000-36	AEK-3000-48	AEK-3000-6	
	DC Voltage Range	12V	15V	24V	30V	36V	48V	60V	
	Rated Current	200A	160A	125A	100A	83.5A	62.5A	50A	
	Current Range	0~200A	0~160A	0~125A	0 ~ 100A	0 ~ 83.5A	0 ~ 62.5A	0 ~ 50A	
	Rated Power	2400W	2400W	3000W	3000W	3006W	3000W	3000W	
	Ripple & Noise (Max.) Note.2	150mVp-p		·					
Output	Voltage Adj. Range	±5.0% Typical ac	djustment by pote	entiometer. (VR1)					
	Voltage Tolerance Note.3	±2.0%							
	Line Regulation	±1.0%							
	Load Regulation	±1.0%							
	Setup, Rise Time	800ms, 50ms at	full load						
	Hold Up Time (Typ.)	14ms / 230VAC	at full load						
	Voltage Range Note.4	90 ~ 264VAC, 12	27 ~ 370VDC						
	Frequency Range	47 ~ 63Hz (Refer to de-rating curve)							
	Power Factor (Typ.)		0.98 / 115VAC at						
Input	Efficiency (Typ.)	88%	89%	91%	91%	92%	92%	93%	
·	AC Current (Typ.)	19.7A / 115VAC	(2000W), 14.5A/	230VAC (3000W	")	1000000	200-2000	January Val	
	Inrush Current (Typ.)	33A / 115VAC, 6	EST STATE OF THE S	,	<u>, </u>				
	Leakage Current	< 1.0mA / 240VA	VC						
	To the state of th	105% rated outp	18 - 11						
	Over Load	The second secon	Constant current	limit					
		Variable OVP, 120 ± 7% Vout. Refer to VCI VS OVP curve.							
Protection	Over Voltage			overy after reset A		nhibit)			
				mary and second		Півісу			
	Over Temperature		2.1	er temperature go					
	Auxiliary Power				CONTRACTOR				
	Remote ON / OFF Control	Selectable +5V / 0.5A or +9V / 0.3A auxiliary output By external switch							
	Power OK Signal	The second secon		turns on Max si	nk current: 20mA	Max. drain volta	ge: 40V.		
Function	Output Voltage Trim			etween 0 ~ 105%	A CONTRACTOR OF THE CONTRACTOR	,	,	0V.	
	Output Current Trim			etween 0 ~ 105%					
		Please refer to p	- Maria and						
	Working Temp.		fer to de-rating c	urve)					
	Working Humidity	20 ~ 90% RH no							
Environment	Storage Temp. & Humidity	-40 ~ +85°C, 10 ~ 95% RH							
	Temp. Coefficient	±0.02% / °C (0 ~							
	Vibration			riod for 60min, each	h along X Y 7 ave	s Compliance to IE	C 60068-2-6 JEC	60068-2-64	
	Safety Standards	Meet UL 60950-	No. of the contract of the con	TOO TOT COTTINIT. COO	Talong X, 1, 2 axo	o compilarios to iz		00000 L 01	
	Withstand Voltage Note.7		•	G: 1.5KVAC (21)	21VDC) O/P-EG:	0.5KVAC (707VE)C)		
	Isolation Resistance	7 I/P-O/P: 3KVAC (4242VDC), I/P-FG: 1.5KVAC (2121VDC), O/P-FG: 0.5KVAC (707VDC) I/P-O/P, I/P-FG, O/P-FG: 100M Ohms / 500VDC							
Safety & EMC	EMI Conduction & Radiation	Certified EN 55022; EN 61204-3; EN 61000-6-3							
	Harmonic & Flicker	Certified EN 61000-3-2; EN 61000-3-3							
			ertified EN 55024; EN 61204-3; EN 61000-6-1; IEC 61000-4-2, 3, 4, 5, 6, 8, 11						
Note.6	Cooling		7797		.0 01000-4-2, 3,	4, 5, 6, 6, 11			
Others	Dimension (WxHxD)	Load and temperature control fan 170x63.5x280 mm / 6.693x2.500x11.024 inch							
Onlers	Packing	3.8kg; 4pcs / 1		X 1 1.024 IIICII					
Note	1. All parameters NOT specially mentione 2. Ripple & noise are measured at 20MH: 3. Tolerance: includes setup time tolerand 4. De-rating may apply in low input voltag 5. In parallel connection only one unit will 6. The power supply is considered a com-	d are measured a z of bandwidth by te, line regulation e. Please check to operate if the tota	at 230VAC input, using a 12" twist and load regulati he de-rating curv al output load is le	ed pair-wire termi on, e for more details ess than 5% of the	nated with a 0.1u e rated power.	F & 47uF parallel	·		

6. The power supply is considered a component which will be installed into a final equipment. The final equipment must be re-confirmed that it still meets



Mechanical Drawings:



AC Input Terminal Pin No. Assignment

Pin No.	Assignment
1	ACL
2	ACN
2	1

Control pin number assignment (CN2): JST S24B-PHDSS or equivalent

Pin No.	Assignment	Pin No.	Assignment	Pin No.	Assignment	Mating H	ousing / Contact
1	VS+	9	EN-	17	AUX		
2	VO+	10	GND	18	GND		
3	VS-	11	EN+	19	SCL		
4	VO-	12	AUX	20	SDA	JST PHDR-24VS	JST SPHD-002T-P0.5
5	POK	13	ACI	21	AUX	or equivalent	or equivalent
6	GND	14	GND	22	GND		
7	PAR	15	VCI	23	NC.		
8	VSET	16	GND	24	NC.		

CN2 Function Description:

Pin No.	Function	Description	Pin No.	Function	Description
1	VS+	Positive output voltage	13	ACI	l Program
2	VO+	Remote sense (+)	14	GND	Ground
3	VS-	Remote sense (-)	15	VCI	V Program
4	VO-	Negative output voltage	16	GND	Ground
5	POK	Power OK	17	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power
6	GND	Ground	18	GND	Ground
7	PAR	Parallel operation current share	19	SCL	Serial Clock used in the I ² C interface
8	VSET	Aux output setting	20	SDA	Serial Data used in the I ² C interface
9	EN-	Inhibit ON/OFF (-)	21	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power
10	GND	Ground	22	GND	Ground
11	EN+	Inhibit ON/OFF (+)	23	NC.	For RS232 Transmission function
12	AUX	+5V / 0.5A or +9V / 0.3A Auxiliary power	24	NC.	For RS232 Receiver function


LED Status:


LED	LED Signal	Status
Solid(Green)		Power OK (Local mode)
Solid(Orange)		Power OK (Remote mode)
Slow Blink(Green)		Power Standby
Fast Blink(Red)		Over Voltage Protection (OVP)
Solid(Red)		Over Load Protection (OLP)
Slow Blink(Red)		Over Temperature Protection (OTP)
Intermittent Blink(Red)		Fan Failure
Interlace Blink(Red)		Power Failure

^{*}Local mode: Use ACI/VCI control output current and voltage.

Remote mode: Use RS-232 or I²C command control output current and voltage.

De-rating Curve:






CMD VS Output Curve:

CTRL

VCI / ACI




A/D

CTRL

VCI VS OVP Curve:

220R




CTRL

VCI / ACI


VC=IC . R

VCI / ACI


Remote ON/OFF:








(B) ON / OFF Control by NPN transistor




(C) Using external voltage source


Power OK Signal:




- *Place an additional capacitor to have a better performance of auxiliary power operation.
- *The grounding of "AUX" power should be connected to "GND" port. If " V-" is connected as Grounding, make sure to short the GND and V- ports.



1. Remote Sense




2. Local Sense (Default setting)




2	
VO+	VS+
VO-	VS-
GND	РОК
VSET	PAR
GND	EN+
AUX	EN+
GND	ACI
GND	VCI
GND	AUX
SDA	SCL
GND	AUX
NC	NC



3. Current Sharing with Remote Sensing




4. Current Sharing with Local Sensing






Installation Instruction:

- 1. Mounting Directions
 - 1-1 Recommended standard mounting methods:



- 2-1 There are ventilating holes on the front and back side panels, do not obstruct; allow 50mm at least for air flow.
- 2-2 The Maximum allowable penetration of screw is 4mm. Incomplete threading should not be penetrated.
- 2-3 Recommended the torque of mounting screw: M4 screw: 1.27N • m (13.0kgf • cm)



Available from



Power sources and test instrumentation solutions

Caltest have been providing power sources and test instrumentation solutions for over 20 years and are proud to represent a number of industry leading manufacturers.

As well as supplying world class power sources and test instrumentation Caltest also has a service centre and UKAS calibration laboratory.

NEED HELP?
CALL US:
01483 302 700

or visit our website for more details

Caltest Instruments Ltd 4 Riverside Business Centre Walnut Tree Close Guildford Surrey GU1 4UG United Kingdom Tel: +44 (0) 1483 302 700 Fax: +44 (0) 1483 300 562 sales@caltest.co.uk www.caltest.co.uk

Sales • Rentals • Service • UKAS Calibration

